



Insert a pin and
(a) Press for 1 Sec to restart
(b) Press for 1 Min for Factory Reset


Reversing the physical switch reverse the current state of the respective switch

GREEN glow of the indicator represent that the respective Switch is ON

RED glow of the indicator represent that the respective Switch is OFF



Indicators Always
represents the true state
of the switches
irrespective of the
physical switch position



The Blue Led represent the connection status

Different blinking speed indicates different errors

1. blinking with 1 second delay indicates no internet
2. blinking with 0.5 second delay indicates no WiFi connection
3. Other different High speed might indicate system level errors

